




Atari 5200 Controller Side Buttons Replacement

A guide to disassembling the Atari 5200 Controller to give its user access to repairing the orange/red side buttons.

Written By: Alan Abelson




Step 1 — Controller Side Buttons



- Turn the controller over, exposing the three screws on the back. Use a 6mm screwdriver to remove these screws.
- Carefully slide and pull the two parts of the controller shell apart, exposing the innards.

Step 2 — A Little Off the Sides



- Now that the top of the controller is exposed, the orange, side buttons can easily slide out.
- Realign the buttons over the sensors/clean the sensor contacts.

⚠ Be careful when reassembling your buttons. Make sure the black buttons are aligned properly over the silver sensors on the flex board


⚠ Also, be careful to properly align the bottom of the joystick with the pots (white levers)

Step 3 — Reassembly Part 1



- Use a spudger to remove the top frame.
- Take off the plate.
- Remove the rubber buttons.

Step 4 — Reassembly Part 2



- Pull the circuit strip through the new space.
- Realign the top and bottom of the controller.

Step 5 — Reassembly Part 3



- Return the buttons to the top of the controller.
- Snap the frame back into place.
- Screw the screws.

To reassemble your device, follow these instructions in reverse order.

